

FIG.1A





FIG. 1B



APPROVED	O.G. FIG.
BY	CLASS SUBCLASS
DRAFTSMAN	

FIG.2






FIG.3A



TO 0280-3004650

FIG.3B



APPROVED BY DRAFTSMAN	O.G. FIG. CLASS SUBCLASS
-----------------------------	-----------------------------

## FIG.3C

82

PICK THE FIRST DIGIT  
OF YOUR AWARD

118

HUNDRED'S  
DIGIT

120

TEN'S  
DIGIT

122

ONE'S  
DIGIT

80

TOO280-E0047500

## FIG.3D

90

118

HUNDRED'S  
DIGIT

120

9

122

ONE'S  
DIGIT



114

GOOD GOING, YOU ADDED NINETY  
CREDITS TO YOUR AWARD, NOW PICK  
SOME MORE HIGH NUMBERS FOR THE  
HUNDRED'S AND THE ONE'S DIGIT

APPROVED	O.G. FIG.
BY	CLASS SUBCLASS
DRAFTSMAN	

100280-E004660





FIG.4



100280-00000000

FIG.6




FIG. 7

30,32

158

PLACE AN X, Y AND Z TO WIN THE JACKPOT

150

118

120

122

A diagram of a 3x5 grid slot machine layout. The grid is divided into 15 cells. The symbols in the cells are as follows:

- Row 1 (Top): 34, 34, 34, 116, 34
- Row 2: 2, 7, Y, 2
- Row 3: 1, BAR, BAR, 1
- Row 4: 1, BAR, BAR, BAR, 1
- Row 5 (Bottom): 3, 7, 3

Each symbol is enclosed in a circle with a number indicating its value. The symbols include a banana, a 7, a Y, a tomato, a bar, cherries, and a bar. The numbers 34, 116, 2, 1, and 3 are circled and connected by lines to the right side of the grid. The numbers 56 are circled and connected to the right side of the grid.

## SELECT LINES

BET PER  
LINE

MAX  
BET

152

154

156

16

FIG. 8





FIG. 9







FIG.10



TELETYPE - TELETYPE - TELETYPE - TELETYPE - TELETYPE - TELETYPE

FIG.11





FIG.12



100280-3004560

FIG.13

